


KeyPilot2






PHONAK
hearing systems



Phonak distributors worldwide

Group companies:	(detailed information on www.phonak.com)
Australia	Phonak Australasia Pty. Ltd. Baulkham Hills N. S. W. 2153
Austria	Hansaton Akustische Geräte GmbH, 5020 Salzburg
Belgium	Lapperre N.V., 1702 Groot-Bijgaarden
Canada	Phonak Canada Limited Mississauga, Ontario L5S 1V9
Denmark	Phonak Danmark A/S Nitivej 10, 2000 Frederiksberg
France	Phonak France SA, 69500 Bron
Germany	Phonak GmbH 70736 Fellbach-Oeffingen, EC Representative
Italy	Phonak Italia S.r.l., 20159 Milano
Japan	Phonak Japan Co., Ltd., Tokyo 101-0044
Jordan	Phonak Middle East, 11181 Amman
Netherlands	Phonak B.V., 3439 ME Nieuwegein
New Zealand	Phonak New Zealand Ltd. Takapuna, Auckland 9
Norway	Phonak AS, 0105 Oslo
Spain	Phonak Ibérica S.A., 03008 Alicante
Sweden	Phonak AB, 117 34 Stockholm
Switzerland	Phonak AG, Phonak Schweiz, 8712 Stäfa

United Kingdom	Phonak UK Limited Warrington, Cheshire WA1 1PP
USA	Phonak LLC, Warrenville, IL 60555-3927
Independent general agents:	A complete list of Phonak distributors is available at Phonak's Internet site: www.phonak.com . Please visit us or ask your hearing care professional for information.
Manufacturer:	Phonak AG, Laubisrütistrasse 28, CH-8712 Stäfa, Switzerland



~70 cm (27 inches)



Battery replacement:

Please send KeyPilot2 to your local Phonak Service Center.

Batteriewechsel:

Schicken Sie bitte den KeyPilot2 an Ihre lokale Phonak Servicestelle.

Remplacement de la pile:

Veillez s.v.p. contacter votre service après-vente local Phonak.

Sustitución de la batería:


envíe el KeyPilot2 a su Centro de Servicio local de Phonak.

Sustituzione pila:

invitare il KeyPilot2 al proprio centro di assistenza Phonak locale.

Voor het vervangen van de batterij:

stuur de KeyPilot2 naar het lokale Phonak Service Center.



CE
0459